



MARK PRECISION AUTOMOTIVE

Instruction Manual:
Quick Deploy Extinguisher Mount



Items included:

- 1x Quick Deploy Extinguisher Mount main body
- 1x Quick Deploy Extinguisher Mount top beam
- 1x 3lb Kidde B/C rated fire extinguisher
- 1x top beam knob
- 1x Torx driver

Fitment:

- Jeep JL Wrangler Unlimited (2018-2024)

Use Guide:

- To make use of your Quick Deploy Extinguisher Mount simply press the side button with one hand and hold onto the bottle with your other to deploy.
- To reinstall an appropriate extinguisher bottle (Kidde 3lb B/C or Kidde 3lb A/B/C) push it towards the mount with the gage facing towards you and the neck of the bottle fitting into the corresponding cut out on the right (passenger) side of the mount, then push the bottom clamp into place until a secure click is felt/heard. The bottle should have very little or no looseness in the mount.

Installation Guide:

1. Begin by removing the Quick Deploy Extinguisher Mount from the packaging and separating the extinguisher from the mount.

2. Separate the top beam of your Quick Deploy Extinguisher mount from the main body by turning the top knob until it comes off.
3. Locate, remove, and set aside the three torx fasteners on your Jeep's rearmost top roll cage cross beam (near the cargo lights). Two are accessible through the rear cargo area and the other is directly opposite of these two, accessible through the rear passenger compartment. These original torx fasteners will be reused to attach the mount.
4. Fasten the Quick Deploy Extinguisher main body via the two threaded holes (accessible through the rear cargo area) with the original torx fasteners using light hand torque. **DO NOT OVERTORQUE OR USE POWER TOOLS.**
5. Opposite of the main body you just installed, fasten the top beam via the single threaded hole (accessible through the rear passenger compartment) with the original torx fastener using light hand torque. Ensure that the exposed stud on the main body passes through the oblong slot on the top beam. **DO NOT OVERTORQUE OR USE POWER TOOLS.**
6. Reattach knob to the exposed stud at the joint between the main body and the top beam. Apply moderate hand torque.
7. Reinstall extinguisher bottle into the mount and check for looseness on the whole system. The mount and bottle should be securely mounted to the roll cage and not able to move. If the mount is not secure, first apply more torque to the top knob. If

the problem persists apply slightly more torque to each of the torx fasteners until secure.

Additional images:



